




User guide for remote control system.

The system has been fully tested before shipment. To use the remote, first connect the power supply to the control box mounted on the roller frame. To avoid damaging the cord while riding, it's best to route it underneath the drums so it exits either at the front or rear of the rollers. If you must route it to the side of the rollers, place it on the floor under the frame. Do not place it over the top of the frame. There are two remotes included with the system. Attach one to the bike's handlebars and keep the other one as a spare.



OPERATION

The resistance system has 4 levels to choose from. Use the buttons on the remote to choose levels I through IV. When the system is powered up, it will automatically seek the level 1 position. The resistance may be adjusted at any time either while riding or stopped.

Resistance	Button
LEVEL 1 easiest	I(red)
LEVEL 2	II
LEVEL 3	III
LEVEL 4 hardest	IV

Resistance system not responding to the remote?

Make sure the light on the remote blinks when any button is pushed. This indicates the remote battery is working.

Make sure the resistance unit is plugged in with the supplied power adapter. There should be a blinking light visible inside the white control box mounted on the roller frame.

Does the resistance automatically shift to LEVEL 1 while riding?

This is likely caused by a loose connection with the power adapter. Make sure the movement of the roller frame does not put strain on the power adapter cord.

V2.2